

MicroStation

Dimension Association

Did you know that dimensions are associated with the Associative Dimension setting in the sheet file. If the Reference file is associated to a dimension upon initial placement, and the reference file is either not found or detached and reattached, the association will be broken. You can drop the dimension through the drop element command (element will become only a graphic group not dimension any longer), place another dimension while associating to the reference file with association selected, or key-in dimension reassociate to associate the dimension again.